

# WJ-ND400 Prevent unexpected access to the recorder

## Change the default user name and password

Network disk recorders can be configured to be accessed from the Internet. However, depending on how the recorders are configured, they may be unexpectedly accessed by the third party, which may cause infringement of privacy rights, leaking of information, and other issues.

If you connect a recorder to the Internet, make sure to configure the following settings.

- ① **Set user name and password, which have been set to camera, to recorder**
- ② **Change the default administrator name and password to new one**
- ③ **Make sure that the user authentication is set to "On"** (factory default is "On")

### Configuration example for above ①

(Refer to the operating instructions provided with your recorder for further information about the settings)

- Preparation 1. Log in to the recorder on the web browser screen, operate by using a mouse.  
2. Click [Setup] > [Camera] > [Setup] button next to [Network camera registration] to display the Network camera registration-setup screen.

Network camera registration-setup screen.



### Register a new user name and password for each camera


After completing the input of all cameras, click the [Set] button.

### Configuration example for above ②

(Refer to the operating instructions provided with your recorder for further information about the settings)

- Preparation 1. Log in to the recorder on the web browser screen, operate by using a mouse.  
2. Click [Setup] > [User mng.] > [Administrator] tab to display the "Administrator" screen.

Administrator screen



### Change the administrator name and password

After changing the administrator name and password, click the [Set] button.

## Cautions for administrator names and passwords

- **Use a combination of characters and numbers that is difficult to guess.**  
Avoid using a string of the same characters, such as "1111", birth dates, or telephone numbers.
- **Change user names and passwords periodically.**
- **Make sure to manage the configured user names and passwords.**
- **Delete all user names that do not have an assigned user.**

## After changing the administrator name and password

Also change the administrator names and passwords registered to the products which are connected to the recorder.  
Refer to the operating instructions provided with your product for further information about the settings used for your products.

# WJ-ND400 レコーダーの第三者アクセス防止のため 初期ユーザー名/パスワードを変更してください

ネットワークディスクレコーダーはインターネット経由でアクセスできるように設定できます。第三者からの意図しないアクセスによるプライバシーや肖像権の侵害、情報漏えいなどを未然に防止するために、必ず以下の設定を行ってください。

- ①カメラに設定したユーザー名/パスワードをレコーダーに設定する
- ②管理者ユーザー名/パスワードを初期設定から変更する
- ③ユーザー認証が On であることを確認する（工場出荷時は On です）

## ①の設定手順（詳しい設定手順は、取扱説明書をお読みください）

- 準備：1. ウェブブラウザ画面で本機にログインし、マウスを使って操作する。  
2. [設定] ⇒ [カメラ] ⇒ 「ネットワークカメラ登録」横の [一覧表示] ボタンの順にクリックして登録情報の変更画面を表示する。

### ネットワークカメラ登録一覧表示画面



カメラごとのユーザー名/パスワードを設定する

⇒すべてのカメラの入力を完了した後に「設定保存」ボタンをクリック

## ②の設定手順（詳しい設定手順は、取扱説明書をお読みください）

- 準備：1. ウェブブラウザ画面で本機にログインし、マウスを使って操作する。  
2. [設定] ⇒ [ユーザー管理] ⇒ [管理者] タブの順にクリックして管理者設定画面を表示する。

### 管理者画面



管理者ユーザー名/パスワードを変更する

⇒入力後に画面下にある「設定保存」ボタンをクリック

## 管理者ユーザー名/パスワード設定時のお願い

- ・容易に推測されない文字と数字の組み合わせで設定してください。  
「11111」などの連続する数字や文字、関係者の生年月日や電話番号は避けてください。
- ・ユーザー名/パスワードは定期的に変更してください。
- ・設定したユーザー名/パスワードは必ず控えておいてください。
- ・管理者が不明のユーザー名は削除してください。

## 管理者ユーザー名/パスワードを変更後は

本機に接続している機器に登録している管理者ユーザー名/パスワードも変更してください。  
製品ごとの設定手順は、お使いの製品の取扱説明書をお読みください。