

Available function list for each compatible device

[Upload Configuration Files] Up to 1024 recorders/cameras/encoders can be registered. Authentication: Supports Basic authentication method.	Recorder							Camera / Encoder / Network Microphone														Network Switch
	ND400	NX400 NX200	NV300	NV200	HD616 HD716	ND300 ND300A ND200	HD350 HD309 HD316A	NP24* NP100* NS202A NF28* NW484 NS9** NF302 NP304 NT304 NT314 GXD400	GXE500 GXE100	NP502 NW502S	VT164(W) VP104(W)	SW397 SW396 SW395	SF448 SW458 SF438	SFN310 SFN311 SFN611L SFN631L	SFN480 SFV481	SFV781L SPV781L S1131 S1112 S1111 S1531L S1511L S2531L S2511L S2231L S2211L S2130 S2111L S2110 X6531N X6511N	S1132 S1131 V1330L1 V1330L1 V1170 V6430L	SMR10	BB-HCM** BB-HCE** BL-C**	MNO Series		
1 The binary file (.bin) will be uploaded to the recorder via HTTP(S)/FTP. *2 The PCS file (*.pcs) will be uploaded to the camera via HTTP(S)/FTP. *3 The DAT file (*.dat) will be uploaded to the camera via HTTP(S). *4 The files in a folder will be uploaded to the encoder via HTTP(S)/FTP. *5 There are many setting items in these cameras, and Processing takes time. *6 Select whether or not to overwrite "Basic - Camera Title". *7 Select whether or not to overwrite "H.264/MPEG-4 - Multicast Address and Port". *8 Select whether or not to overwrite Network Settings. *9 Network setting and time & date will not be changed even after uploading the setup file. *10 Use the old version of this software. *11 Detects devices connected to the target network automatically.	○ *1,*8	○ *1,*8,*11	○ *1,*8,*11	○ *1,*8,*11	○ *1	- *10	-	- *10	○ GXE500 *4,*7,*9, *11 ○ GXE100 *2,*6,*7, *9,*11	○ *2,*6,*7, *9,*11	○ *2,*6,*7, *9,*11	○ *2,*6,*7, *9,*11	○ *3,*6,*7, *9,*11	○ *3,*6,*7, *9,*11	○ *3,*6,*7, *9,*11	○ *3,*6,*7, *9,*11	-	○ *3,*9,*11	-	-		

[Upgrade Firmware] Up to 1024 recorders/cameras/encoders can be registered. Authentication: Supports Basic authentication method.	Recorder							Camera / Encoder / Network Microphone														Network Switch
	ND400	NX400 NX200	NV300	NV200	HD616 HD716	ND300 ND300A ND200	HD350 HD309 HD316A	NP24* NP100* NS202A NF28* NW484 NS9** NF302 NP304 NT304 NT314 GXD400	GXE500 GXE100	NP502 NW502S	VT164(W) VP104(W)	SW397 SW396 SW395	SF448 SW458 SF438	SFN310 SFN311 SFN611L SFN631L	SFN480 SFV481	SFV781L SPV781L S1131 S1112 S1111 S1531L S1511L S2531L S2511L S2231L S2211L S2130 S2111L S2110 X6531N X6511N	S1132 S1131 V1330L1 V1330L1 V1170 V6430L	SMR10	BB-HCM** BB-HCE** BL-C**	MNO Series		
*1 Select whether or not to initialize the settings after completing the firmware upgrade. *2 The settings are not initialized after completing the firmware upgrade. ① Auto Select upgrade *3 Select the latest version of firmware automatically. Upgrade the firmware of the various devices at a time. ⇒ Do not change the folder and file name which extract the downloaded ZIP file from Panasonic site. ② Individual designation upgrade *4 Select the firmware individually. Each individual model will be upgraded. *5 Use the old version of this software. *6 Detects devices connected to the target network automatically.	① ② ○ *2,*3,*4	○ *2,*3, *4,*6	○ *2,*3, *4,*6	○ *2,*3, *4,*6	○ *2,*3,*4	- *5	- *5	○ *1,*3, *4,*6	○ *1,*3, *4,*6	○ *1,*3, *4,*6	○ *1,*3, *4,*6	○ *1,*3, *4,*6	○ *1,*3, *4,*6	○ *1,*3, *4,*6	○ *1,*3, *4,*6	○ *1,*3, *4,*6	-	○ *1,*3, *4,*6	-	-		